



EPSILON E50 TOOL CHANGE SYSTEM

95620, Rev 00

March 31, 2016

648 Saratoga Road
Glenville, NY 12302 USA
Phone: 518 384 1000
Fax: 518 384 1200
www.appliedrobotics.com

REVISION

Revision	Date	Author	Description
00	3/31/2016	SC	Initial Release

All rights reserved. Copyright © 1986—2016 Applied Robotics Inc.

The use of this document is reserved exclusively for the use of Applied Robotics Incorporated customers and personnel. The information and drawings contained herein are the sole property of Applied Robotics Incorporated and shall not be divulged to any third party without the prior written consent of Applied Robotics Inc. The information in this document is subject to change without notice.

Applied Robotics makes no warranty of any kind with regard to this user's guide, including but not limited to, implied warranties or fitness for a particular purpose. Applied Robotics Inc. shall not be liable for any errors contained herein or for incidental or consequential damages in connection with the performance or use of this material.

CONTENTS

1	LIFETIME GUARANTEE	5
2	PRECAUTIONS	6
3	SYSTEM DESCRIPTION	7
3.1	ROBOT ADAPTOR	8
3.2	TOOL ADAPTOR.....	9
4	TECHNICAL SPECIFICATIONS	10
5	INSTALLATION	11
5.1	ROBOT ADAPTOR INSTALLATION	11
5.2	TOOL ADAPTOR INSTALLATION.....	13
5.3	CONNECTING THE AIR SUPPLY.....	16
5.4	COUPLE & UNCOUPLE SIGNALS (OPTIONAL).....	17
5.5	TOOL PRESENT SIGNAL (OPTIONAL).....	18
5.6	CONNECTING USER PNEUMATIC PORTS.....	20
6	GUIDE TO OPERATION.....	21
6.1	INITIAL TEST	21
6.2	PROGRAMMING THE COUPLE AND UNCOUPLE POINTS	22
6.3	RECOMMENDED SEQUENCE OF OPERATION.....	25
7	TROUBLESHOOTING.....	31
7.1	TECHNICAL SUPPORT	31
7.2	TROUBLESHOOTING GUIDE	31
7.3	TROUBLESHOOTING FAULT TREE	32
7.4	MANUAL UNCOUPLE.....	33
8	MAINTENANCE.....	34
8.1	PREVENTIVE MAINTENANCE	36
8.1.1	Lubrication.....	36
8.1.1.1	Robot Adaptor	36
8.1.1.2	Tool Adaptor	37
8.1.2	Visual Checks	38
8.1.2.1	Robot Adaptor	38
8.1.2.2	Tool Adaptor	39
8.1.3	Checking Wear of the Cam Locking Mechanism.....	39
9	SPARE PARTS	42
10	SPARE PARTS REPLACEMENT.....	43
10.1	ROBOT ADAPTOR	43

10.1.1 Locating/Alignment Pins 43

10.1.2 Couple/Uncouple Sensing Module (Optional Feature) 44

10.2 TOOL ADAPTOR..... 45

10.2.1 Locking Ring 45

10.2.2 Locating Bushing 46

11 INFORMATIONAL DRAWINGS..... 47

1 LIFETIME GUARANTEE

APPLIED ROBOTICS extends a lifetime guarantee to the components that make up the operating cam locking mechanism of the Epsilon Tool Changer. The following components are covered under APPLIED ROBOTICS Lifetime Guarantee.

PART NUMBER	DESCRIPTION
96504-P1018	NUT, NYLON LOCK M5
96503-B1040	PISTON, BOLT ROBOT
96503-C1071	CAM, ROBOT
96503-B1039	PIVOT PIN, ROBOT
96503-B1054	LOCK RING, TOOLING

APPLIED ROBOTICS warrants the Epsilon Tool Changer cam locking mechanism **for the lifetime of the product against manufacturer's defects in materials and workmanship**. Additionally, APPLIED ROBOTICS warrants the cam locking mechanism against wear that results in the Epsilon Tool Changer to lose repeatability and precision during the docking sequence of operation (Section 8.1.3).

CONDITIONS OF THE WARRANTY:

Products shall have been subject to only normal use and service as instructed in this manual and shall not have been misused, neglected, altered, improperly set up or otherwise damaged; and, there shall be no evidence of tampering or deliberate misuse or destruction.

Defects to APPLIED ROBOTICS products will be determined solely by APPLIED ROBOTICS and not by any representative or distributor of or for APPLIED ROBOTICS. Upon determination of a defect, APPLIED ROBOTICS sole obligation will be to provide replacement material for the defective part(s). APPLIED ROBOTICS is not liable or responsible for costs borne from lost production or labor related costs for repairing the defective part(s).

Any claim against APPLIED ROBOTICS for defects in material or workmanship must be in writing. APPLIED ROBOTICS must authorize the return of any allegedly defective part before it is returned. The party making the claim must prepay all shipping and transportation costs. APPLIED ROBOTICS will not accept charges for parts purchased unless the conditions of the warranty have been satisfied.

No APPLIED ROBOTICS representative or distributor is authorized to assume for APPLIED ROBOTICS any other obligations or liabilities in connection with the product, or alter the terms of this warranty in any way.

APPLIED ROBOTICS shall not be liable for damages, including special, incidental or consequential damages arising out of or in connection with the performance of an APPLIED ROBOTICS product or its use by the owner.

2 PRECAUTIONS



READ MANUAL

Do not start, operate or service machine until **you read and understand operator's manual.** Failure to do so could result in serious injury.



HAND CRUSH NOTICE

Indicates the possibility for a crush force between components during coupling of the Robot and Tool Adaptor.



Indicates a hazardous situation which, if not avoided, will result in death or serious injury.



Indicates a hazardous situation which, if not avoided, could result in death or serious injury.



Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



Indicates a situation which, if not avoided, could result in equipment damage and voiding the manufacturer's equipment warranty.

IGNORING INFORMATION ABOUT POTENTIAL HAZARDS CAN LEAD TO SERIOUS HARM TO PERSONNEL AND/OR DAMAGE TO THE EQUIPMENT, AND MAY RESULT IN THE NULLIFICATION OF THE MANUFACTURER'S EQUIPMENT WARRANTY.

HEED ALL PRECAUTION NOTICES

3 SYSTEM DESCRIPTION

The Epsilon E50 Tool Changer provides a strong and reliable method for a manipulator to quickly change between different tools/end-effectors. With Applied Robotics, Inc. modular design, the E50 Tool Changer offers the maximum flexibility for any application.

The E50 Tool Changer contains two major components:

Robot Adaptor (ER50) – Mounts directly to a robot flange utilizing a 50mm ISO 9409-1 pattern without the need for adaptor plates (Figure 3-1).

Tool Adaptor (ET63) – Mounts directly to a tooling plate utilizing a 63mm ISO 9409-1 pattern (Figure 3-2).

The Robot Adaptor and Tool Adaptor lock together by means of a double-acting, pneumatically-driven cam locking mechanism. The three (3) cam self-centering locking mechanism allows for reliable and repeatable operation throughout the life of the tool changer with a unique wear compensating design. As the locking mechanism actuates, the Tool Adaptor is physically connected and disconnected along with any utilities contained in the attached modules.




Figure 3-1. ER50 Robot Adaptor






Figure 3-2. ET63 Tool Adaptor

3.1 ROBOT ADAPTOR



3.2 TOOL ADAPTOR



4 TECHNICAL SPECIFICATIONS

Table 4-1. E50 Technical Specifications

Specification		Metric	English
Payload		25 Kg	55 lb
Maximum Operating Moment (Mx, My)		88 Nm	780 in-lb
Maximum E-Stop Moment (Mx, My)		168 Nm	1,485 in-lb
Maximum Operating Torque (Mz)		120 Nm	1,060 in-lb
Maximum E-Stop Torque (Mz)		375 Nm	3,320 in-lb
Maximum Tensile Force (F _T)		3,336 N	750 lb
Maximum Compressive Force (F _C)		17,837 N	4,010 lb
Diameter		85 mm	3.35 in
Height (Robot and Tool Coupled)		48 mm	1.89 in
Mass / Weight	Robot	0.38 Kg	0.84 lb
	Tool	0.21 Kg	0.46 lb
Positional Repeatability X, Y & Z axis		+/- 0.02 mm	+/- 0.0008 in
Operating Temperature		5 - 60 °C	40 - 140 °F
Supply Pressure		5 – 7 bar	72 - 101 psi
Couple/Uncouple Voltage (Optional)		10 – 30 Vdc	10 – 30 Vdc
User Pneumatic Pressure Range		0 – 7 bar	0 – 101 psi
User Pneumatic Flow (CFM)		**Contact Applications Engineering**	

5 INSTALLATION

5.1 ROBOT ADAPTOR INSTALLATION

The E50 Robot Adaptor is designed to mount directly to interfaces utilizing an ISO 50mm bolt pattern (ISO 9409-1). The E50 Robot Adaptor can mount to manipulator interfaces utilizing M6 hardware. For size, locations, and tolerance information on the E50 Robot Adaptor mounting patterns, see APPLIED ROBOTICS drawing number 1507-D40A.

NOTICE

TOOL CHANGER PAYLOAD & MOMENT RATINGS BASED ON USING A MINIMUM OF 4xM6 SCREWS TO MOUNT THE ROBOT ADAPTOR TO THE MANIPULATOR INTERFACE.

Installing the E50 Robot Adaptor Using M6 Hardware:**NOTICE**

ENSURE THAT THE MATING SURFACES OF THE ROBOT ADAPTOR AND ROBOT FLANGE ARE FLUSH (PLANAR) WHEN FASTENING THE SCREWS.

1. Locate the Robot Adaptor to the manipulator mounting flange utilizing the locating boss and one (1) M6 locating dowel (Figure 5.1-1).
2. Insert and tighten the M6 socket head cap screws (minimum Property Class 10.9) provided with the Robot Adaptor Assembly. Torque the screws to the robot manufacturer's specification.

NOTICE

TIGHTEN FACEPLATE MOUNTING SCREWS TO ROBOT MANUFACTURER'S SPECIFICATIONS. IF USING LOCTITE, USE LOCTITE 242 OR EQUIVALENT.




Figure 5.1-1. E50 Robot Adaptor Installation w/ M6 Hardware

**WARNING**

DO NOT EXCEED THE MAXIMUM OPERATING OR E-STOP MOMENT OF THE TOOL CHANGER WHEN USING A ROBOT ADAPTOR PLATE TO ADAPT TO OTHER BOLTING PATTERNS.

5.2 TOOL ADAPTOR INSTALLATION

The E50 utilizes the same Tool Adaptor as the E63 (ET63) and is designed to mount directly to customer tooling utilizing an ISO 9409-1 bolt pattern. The Tool Adaptor can be mounted from the top down using M6 hardware on the ISO 63mm bolt circle. For size, locations, and tolerance information on the E50 Tool Adaptor mounting patterns, see APPLIED ROBOTICS drawing number 1507-D49A.

NOTICE

TOOL CHANGER PAYLOAD & MOMENT RATINGS BASED ON USING 4xM6 SCREWS TO MOUNT THE TOOL ADAPTOR TO THE TOOLING INTERFACE.

If a locating boss/pilot is used on the tool plate to locate the tool to the Tool Adaptor, then the boss cannot protrude into the tool changer greater than 4mm and a 32mm diameter counter-bore with a minimum depth of 2mm below the Tool Adaptor and Tool Plate interface must be made into the boss to allow for clearance of the latching mechanism (Figure 5.2-1).




Figure 5.2-1. ET63 Tool Adaptor and Tool Plate Installation (w/ Pilot)

Alternatively, if a locating boss/pilot is not used to locate the tool plate to the Tool Adaptor and two (2) locating dowels are used instead, then a 15mm diameter counter-bore with a minimum depth of 2mm must be made into the tool plate to allow for clearance of the latching mechanism (Figure 5.2-2).




Figure 5.2-2. ET63 Tool Adaptor and Tool Plate Installation (No Pilot)

Installing the ET63 Tool Adaptor From the Top Down:**NOTICE**

ENSURE THAT THE MATING SURFACES OF THE TOOL ADAPTOR AND TOOL PLATE ARE FLUSH (PLANAR) WHEN FASTENING THE SCREWS.

1. Locate the Tool Adaptor to the tool plate utilizing either the locating hub and one (1) M6 locating dowel, or two (2) M6 locating dowels (Figure 5.2-3).
2. Insert and tighten M6 socket head cap screws (minimum Property Class 10.9) through the Tool Adaptor 63mm bolt circle. Applied Robotics recommends the use of steel threads in the tool plate and appropriate thread engagement and torque values.

NOTICE

TIGHTEN MOUNTING SCREWS TO THE APPROPRIATE SPECIFICATION DEPENDING ON THE END EFFECTOR USED. IF USING LOCTITE, USE LOCTITE 242 OR EQUIVALENT.




Figure 5.2-3. ET63 Tool Adaptor Installation (Bolt Top Down)

WARNING

DO NOT EXCEED THE MAXIMUM OPERATING OR E-STOP MOMENT OF THE TOOL CHANGER WHEN USING A ROBOT ADAPTOR PLATE TO ADAPT TO OTHER BOLTING PATTERNS.

5.3 CONNECTING THE AIR SUPPLY

The pneumatic supply for the Epsilon Tool Changer can be supplied via directly ported air fittings supplied by the customer (Figure 5.3-1).



PNEUMATIC PRESSURE SHOULD NEVER BE SUPPLIED TO THE EPSILON TOOL CHANGE SYSTEM UNLESS THE POSITION OF THE VALVE SUPPLYING THE AIR IS KNOWN AND HAS BEEN CONFIRMED. FAILURE TO DO SO CAN RESULT IN SERIOUS INJURY OR DEATH FROM A DROPPED TOOL.



THE ROBOT SHOULD NEVER BE RUN WITHOUT AIR PRESSURE BEING SUPPLIED TO THE TOOL CHANGER. PRESSURE TO THE TOOL CHANGER MUST BE AT LEAST 5 BAR (72 PSIG) FOR PROPER OPERATION.




Figure 5.3-1. E50 Robot Adaptor Air Supply Ports

Both the couple and uncouple actuation port lines must be installed in order for the Epsilon Tool Change System to function properly. To control air to the different ports, a single solenoid, spring-return, 4-way valve or a double solenoid, 4-way valve can be used.

**WARNING****IF A SINGLE SOLENOID, SPRING-RETURN, 4-WAY PNEUMATIC VALVE IS USED, THE FOLLOWING MUST BE UNDERSTOOD AND ADHERED TO:**

- IN THE DE-ENERGIZED STATE, THE VALVE MUST PROVIDE AIR TO THE COUPLE PORT ONLY.

IF A DOUBLE SOLENOID, 4-WAY PNEUMATIC VALVE IS USED, THE FOLLOWING MUST BE UNDERSTOOD AND ADHERED TO:

- THE VALVE WILL REMAIN IN ITS PRESENT POSITION UNTIL EITHER THE ALTERNATE SOLENOID IS ENERGIZED OR BY MANUALLY PRESSING THE ALTERNATE SOLENOID OVERRIDE BUTTON (IF APPLICABLE).
- TO CHANGE THE STATE OF THE VALVE, ONE SIDE OF THE SOLENOID MUST BE ENERGIZED AND THE OTHER SIDE DE-ENERGIZED. IF BOTH SIDES ARE ENERGIZED (OR DE-ENERGIZED), THE VALVE WILL NOT CHANGE STATES.
- THE VALVE MUST BE PILOT ACTUATED SO THAT THE POSITION OF THE VALVE WILL NOT CHANGE UNLESS THERE IS AIR SUPPLIED TO THE VALVE.

**WARNING**

5.4 COUPLE & UNCOUPLE SIGNALS (OPTIONAL)

Couple and uncouple signals are optional on the E50 Robot Adaptor and are provided via an M12 connection (Figure 5.4-1). APPLIED ROBOTICS utilizes proximity switches to provide indication of piston limit positions (couple and uncouple). Switches are preset at the factory and do not require any adjustment for the lifetime of the tool changer.

**CAUTION****COUPLE AND UNCOUPLE SENSOR SIGNALS SHOULD BE CONTINUALLY MONITORED TO VERIFY THAT THE TOOL CHANGER IS IN THE PROPER STATE BEFORE COMMANDING THE ROBOT TO MOVE.**

Should the switches need to be replaced, see Section 10.1.2.




Figure 5.4-1. Couple/Uncouple Signal Interface (Optional)

NOTICE

MAKING CONNECTIONS WHILE UNDER POWER COULD RESULT IN DAMAGE TO THE EQUIPMENT. TO AVOID DAMAGING EQUIPMENT, ENSURE THAT ALL CABLES ARE CONNECTED BEFORE SUPPLYING POWER TO THE EQUIPMENT.

5.5 TOOL PRESENT SIGNAL (OPTIONAL)

The E50 Tool Changer contains a built in feature for Tool Present detection via a proximity sensor(s) (Figure 5.5-1). This option provides direct detection of the Tool Adaptor and the signal can be directly monitored by the robot controller.




Figure 5.5-1. Tool Present Option

When the Tool Present sensors are installed, ensure that the tip of the sensor (highlighted blue) does not protrude past the Robot Adaptor interface (Figure 5.5-2).




Figure 5.5-2. Tool Present Sensor Installation

5.6 CONNECTING USER PNEUMATIC PORTS

The E50 Tool Changer has 8 available user pneumatic ports to supply air through the tool changer to the specific tool being used. The tool changer must be coupled and be fitted with an o-ring seal for these ports to be operational. Air can be supplied via directly ported air fittings supplied by the customer (Figure 5.6-1).




Figure 5.6-1. E50 User Pneumatic Ports

6 GUIDE TO OPERATION

6.1 INITIAL TEST

Once the air supply has been plumbed to the couple and uncouple ports, control power is connected to the air supply valve, and the couple and uncouple position sensors are in communication with the robot controller/PLC, perform the following steps to verify the proper operation of the Epsilon Tool Changer.



DURING TESTING, KEEP YOUR FINGERS CLEAR OF THE MECHANICAL COUPLING MECHANISM AND THE COUPLING INTERFACE SURFACES. KEEP OUT OF THE ROBOT WORK ENVELOPE WHEN DRIVE POWER IS ON.

1. Verify that the Robot Adaptor is clear of any obstruction and not coupled to the Tool Adaptor.
2. Turn on supply air to the control valve and verify that the cams move to the extended position (Figure 6.1-1). If using a single solenoid, spring return, 4-way valve, this will verify that it is plumbed correctly.
3. Supply control power to the solenoid valve and supply the signal from the controller/PLC to move the valve to the uncoupled (solenoid energized) position. The cams should retract to the uncoupled position (Figure 6.1-2) and the input from the uncoupled sensor (optional) should be received by the robot controller/PLC.
4. Change the state of the solenoid valve by turning off the uncouple signal (solenoid de-energized). The cams should extend back to the couple position and the uncouple sensor (optional) signal should turn OFF (LOW) and the couple sensor signal should turn ON (HIGH) at the robot controller/PLC.
5. Repeat steps 3 and 4 several times. The cam action should be smooth and quick.




Figure 6.1-1. Robot Adaptor Coupled (Cams Extended)




Figure 6.1-2. Robot Adaptor Uncoupled (Cams Retracted)

6.2 PROGRAMMING THE COUPLE AND UNCOUPLE POINTS



THE ROBOT SHOULD NEVER BE RUN WITHOUT A MINIMUM AIR PRESSURE OF 5 BAR (72 PSIG) BEING SUPPLIED TO THE ROBOT ADAPTOR.

When programming the “dock” and “undock” points of each tooling, the following steps should be taken:

1. Orient the Robot Adaptor and Tool Adaptor so that the centerline axes are aligned and the interface surfaces are parallel. Maintain approximately 25mm minimum separation between the Robot Adaptor and Tool Adaptor interface surfaces (Figure 6.2-1).




Figure 6.2-1. E50 Tool Changer – Docking Orientation

2. Energize the solenoid, resulting in an uncoupled (cams retracted) state.
3. Rotate the Robot Adaptor so that the locating pins are centered on the bushings in the Tool Adaptor.
4. Start to bring the Robot and Tool Adaptors together while visually checking the alignment of the locating pins and bushings. Make lateral adjustments as necessary to center the locating pins to the bushings. Exact alignment is not required; however limit the amount of interference between the locating pins and bushings while docking. Interference between the locating pins and bushings while docking increases wear and decreases the life of the locating pins.
5. Stop the motion when the distance between the Robot Adaptor interface surface and Tool Adaptor interface surface are touching or as close as can reasonably be achieved. At this time, any electrical or fluid connections will be made through the use of available side modules. Note that when the interface surfaces of the Robot Adaptor and Tool Adaptor are in contact, the outer edge of the Adaptors should be touching (Figure 6.2-2).




Figure 6.2-2. E50 Tool Changer – Docked Position

MINIMIZING THE DISTANCE BETWEEN THE ROBOT ADAPTOR AND TOOL ADAPTOR INTERFACE SURFACES WHEN PROGRAMMING THE DOCK AND UNDOCK POINTS WILL ENSURE OPTIMUM PERFORMANCE OF THE TOOL CHANGER OVER ITS OPERATIONAL LIFE SPAN.

NOTICE

SEPARATION BETWEEN THE ROBOT ADAPTOR AND TOOL ADAPTOR INTERFACE SURFACES, GREATER THAN 1mm DURING DOCKING OR UNDOCKING WILL RESULT IN ADDITIONAL WEAR TO THE TOOL CHANGER AND REDUCE THE OVERALL LIFE EXPECTANCY.

6. De-energize the solenoid that controls the air pressure to the couple port. This will couple the Robot Adaptor with the Tool Adaptor.
7. Cycle the cams by energizing and de-energizing the solenoid several times to verify that the Tool Adaptor is properly connected and released from the Robot Adaptor. If properly programmed, the Robot Adaptor and Tool Adaptor should not move when the cams are coupled (extended) and uncoupled (retracted).
8. Record the **position from Step 5 as the “dock” and “undock” coordinates** for the Tool Adaptor. Depending on the docking station used, separate dock and undock positions may be required.
9. Repeat procedure for each Tool Adaptor used in conjunction with the corresponding Robot Adaptor.

6.3 RECOMMENDED SEQUENCE OF OPERATION



THE EPSILON TOOL CHANGER SYSTEM SHOULD NEVER BE UNCOUPLED UNLESS THE ATTACHED TOOL IS FULLY SUPPORTED IN A DOCKING STATION/TOOL STAND.

The following is a standard sequence of operation for a Robot, Tool Changer, and Tool combination. See Figure 6.3-1 for a graphical representation of this sequence. Note that the **BOLD** indicates a change in status and not all signals may be applicable to your application.

1. The Tool Changer is in the uncoupled state (cams retracted) and in the **"Home"** position (Tool Changer out of the tool stand with NO tool, all tool stand covers are closed, and air supply is ON).

INPUTS:

Uncouple Signal	HIGH
Couple Signal.....	LOW
Ready to Couple Signal	LOW
Tool Present Signal.....	LOW
Tool Stand Present Signal.....	LOW
Tool Cover Open Signal.....	LOW
Tool Cover Closed Signal.....	HIGH

OUTPUTS:

Uncouple Command.....	HIGH
Tool Cover Open Command	LOW
Tool Cover Close Command	HIGH

2. Open tool stand cover.

INPUTS:

Uncouple Signal	HIGH
Couple Signal.....	LOW
Ready to Couple Signal	LOW
Tool Present Signal.....	LOW
Tool Stand Present Signal.....	LOW
Tool Cover Open Signal.....	HIGH
Tool Cover Closed Signal.....	LOW

OUTPUTS:

Uncouple Command.....	HIGH
Tool Cover Open Command	HIGH
Tool Cover Close Command	LOW

3. Move to **"Pre-Dock"** position (Approximately 25mm above the Tool Adaptor).

INPUTS:

Uncouple Signal	HIGH
Couple Signal.....	LOW
Ready to Couple Signal	LOW
Tool Present Signal.....	LOW
Tool Stand Present Signal.....	LOW
Tool Cover Open Signal	HIGH
Tool Cover Closed Signal.....	LOW

OUTPUTS:

Uncouple Command.....	HIGH
Tool Cover Open Command	HIGH
Tool Cover Close Command	LOW

4. Move to the “Dock” position (See Section 6.2). Once Robot and Tool Adaptors are within range (~0.75mm or closer), the electrical contacts on the side modules will begin to communicate.

INPUTS:

Uncouple Signal	HIGH
Couple Signal.....	LOW
Ready to Couple Signal	HIGH
Tool Present Signal.....	HIGH
Tool Stand Present Signal.....	HIGH
Tool Cover Open Signal	HIGH
Tool Cover Closed Signal.....	LOW

OUTPUTS:

Uncouple Command.....	HIGH
Tool Cover Open Command	HIGH
Tool Cover Close Command	LOW

5. Once in the “Dock” position, Couple to the tool.

INPUTS:

Uncouple Signal	LOW
Couple Signal.....	HIGH
Ready to Couple Signal	HIGH
Tool Present Signal.....	HIGH
Tool Stand Present Signal.....	HIGH
Tool Cover Open Signal	HIGH
Tool Cover Closed Signal.....	LOW

OUTPUTS:

Uncouple Command.....	LOW
Tool Cover Open Command	HIGH
Tool Cover Close Command	LOW

6. **Move to the “Post-Dock” position.** Ensure the pins and bushings on the docking fixture are clear from one another before leaving the docking station.

INPUTS:

Uncouple Signal	LOW
Couple Signal.....	HIGH
Ready to Couple Signal	HIGH
Tool Present Signal.....	HIGH
Tool Stand Present Signal.....	LOW
Tool Cover Open Signal.....	HIGH
Tool Cover Closed Signal.....	LOW

OUTPUTS:

Uncouple Command.....	LOW
Tool Cover Open Command	HIGH
Tool Cover Close Command	LOW

7. The Robot performs the specified task with the connected tool. Depending on the cell layout and operation being performed, the Tool Cover may need to be closed to avoid interference.

INPUTS:

Uncouple Signal	LOW
Couple Signal.....	HIGH
Ready to Couple Signal	HIGH
Tool Present Signal.....	HIGH
Tool Stand Present Signal.....	LOW
Tool Cover Open Signal.....	HIGH
Tool Cover Closed Signal.....	LOW

OUTPUTS:

Uncouple Command.....	LOW
Tool Cover Open Command	HIGH
Tool Cover Close Command	LOW

8. **Return to the “Post-Dock” position (alternatively could identify a “Pre-Undock” position) after completing the task.**

INPUTS:

Uncouple Signal	LOW
Couple Signal.....	HIGH
Ready to Couple Signal	HIGH
Tool Present Signal.....	HIGH
Tool Stand Present Signal.....	LOW
Tool Cover Open Signal.....	HIGH
Tool Cover Closed Signal.....	LOW

OUTPUTS:

Uncouple Command.....	LOW
Tool Cover Open Command	HIGH
Tool Cover Close Command	LOW

9. Move to the “Dock” position (alternatively, could identify an “Undock” position) with the tool.

INPUTS:

Uncouple Signal	LOW
Couple Signal.....	HIGH
Ready to Couple Signal	HIGH
Tool Present Signal.....	HIGH
Tool Stand Present Signal.....	HIGH
Tool Cover Open Signal	HIGH
Tool Cover Closed Signal	LOW

OUTPUTS:

Uncouple Command.....	LOW
Tool Cover Open Command	HIGH
Tool Cover Close Command	LOW

10. Once in the “Dock”/“Undock” position and the weight is fully supported by the docking station, Uncouple the Tool Changer.

INPUTS:

Uncouple Signal	HIGH
Couple Signal.....	LOW
Ready to Couple Signal	HIGH
Tool Present Signal.....	HIGH
Tool Stand Present Signal.....	HIGH
Tool Cover Open Signal	HIGH
Tool Cover Closed Signal	LOW

OUTPUTS:

Uncouple Command.....	HIGH
Tool Cover Open Command	HIGH
Tool Cover Close Command	LOW

11. Move to the “Pre-Dock” (alternatively, could identify a “Post-Undock” position). Once Robot and Tool Adaptors are separated by approximately 0.75mm, the electrical contacts on the side modules will lose contact and the robot side modules will lose communication with the tool side modules.

INPUTS:

Uncouple Signal	HIGH
Couple Signal.....	LOW
Ready to Couple Signal	LOW

Tool Present Signal.....	LOW
Tool Stand Present Signal.....	LOW
Tool Cover Open Signal.....	HIGH
Tool Cover Closed Signal.....	LOW

OUTPUTS:

Uncouple Command.....	HIGH
Tool Cover Open Command	HIGH
Tool Cover Close Command	LOW


12. Move back to the "Home" position and close the tool stand cover.

INPUTS:

Uncouple Signal	HIGH
Couple Signal.....	LOW
Ready to Couple Signal	LOW
Tool Present Signal.....	LOW
Tool Stand Present Signal.....	LOW
Tool Cover Open Signal	LOW
Tool Cover Closed Signal.....	HIGH

OUTPUTS:

Uncouple Command.....	HIGH
Tool Cover Open Command	LOW
Tool Cover Close Command	HIGH



¹ Customer is required to continuously monitor the SCM OK signal, verifying that the signal remains HIGH throughout the entire operation. If SCM OK signal goes LOW, stop the robot, remove the Uncouple Commands and refer to the Troubleshooting section.

² Signals (dual channel) are only available via LED's on ARI's Safety Control Module (SCM). Not available for monitoring by the robot controller.

³ Second Uncouple Command is required when using ARI's Safety Control Module (SCM) and should be applied simultaneously with the first Uncouple Command.

- Verify the status of all signals before proceeding to the next step.

- Input/Output HIGH = 1, LOW = 0

- Dotted circles indicate a intermediate state of an actuating cyclinder when neither "Open" or "Close" signal is present.

Figure 6.3-1. Sequence of Operations Diagram

7 TROUBLESHOOTING

7.1 TECHNICAL SUPPORT

If you require assistance, contact APPLIED ROBOTICS Technical Support Department at:

Phone: +1 518 384-1000
E-mail: techsupport@appliedrobotics.com.


7.2 TROUBLESHOOTING GUIDE

Table 7.2-1. Troubleshooting Guide

Symptom	Possible Cause	Resolution
Tool Changer Will Not Couple	Tool Changer not within required distance for coupling (<1mm)	Adjust Robot program to move within the required distance (<1mm)
	Electrical connection to the actuation valve has been lost (only if using double-acting solenoid)	Verify all connections are in place and that valve is not damaged and operating correctly
Tool Changer Will Not Uncouple	Air supply to the Tool Changer has been lost	Verify all air connections are in place and air is being supplied to the Robot cell
	Electrical connection to the actuation valve has been lost	Verify all connections are in place and that valve is not damaged and operating correctly
	Tool is not in Tool Stand	Verify the tool is supported in the tool stand and that the Tool Stand Present signal is activated
	Spring Failure	Replace piston spring
Tool Changer Couples, But No Coupled Signal is Being Received	Coupled sensing (optional) has failed	Replace sensor puck (See Section 10.1.2)
	Cable/Connections supplying signal failed	Inspect cables/connections and replace if necessary
	Air supply to the Tool Changer has been lost (Coupled via the sender spring)	Verify all air connections are in place and air is being supplied to the Robot cell
Tool Changer Uncouples, But No Uncoupled Signal is Being Received	Uncoupled sensing (optional) has failed	Replace sensor puck (See Section 10.1.2)
	Cable/Connections supplying signal failed	Inspect cables/connections and replace if necessary

7.3 TROUBLESHOOTING FAULT TREE

The fault tree provides guidance for troubleshooting a Tool Changer Couple/Uncouple signal fault (Optional).



7.4 MANUAL UNCOUPLE

A feature has been designed into the E50 Tool Changer that allows the system to be manually uncoupled in the event that damage occurs that prevents the system from uncoupling under normal means.



ENSURE THAT THE ATTACHED TOOLING IS SAFELY SUPPORTED, PREFERABLY IN ITS TOOL STAND.

The following steps must be followed to ensure that the E50 Tool Changer is manually uncoupled in a safe manner:

1. Ensure that the attached tooling is safely supported, preferably in its tool stand, so that no damage or personal injury occurs when the tool is released.
2. Ensure that all unnecessary personnel are clear of the tooling before going further in this procedure.
3. Shut off the air supply to the actuating cylinder. The cylinder must not be pressurized for this operation to be performed successfully.
4. Insert a M3x25mm long socket head cap screw in the hole located in the middle of the Tool Adaptor Housing as shown in Figure 7.4-1. This requires any tool side modules to be removed.
5. Drive the M3 screw in until the cams are fully retracted. This action will allow the tool changer to uncouple.



WHEN AIR SUPPLY IS OFF, THE COUPLE/UNCOUPLE SIGNALS WILL BE LOST DUE TO THE LACK OF AIR. ONLY MOVE THE ROBOT AFTER THE CAMS HAVE BEEN FULLY RETRACTED.




Figure 7.4-1. Manual Uncouple Feature

8 MAINTENANCE

NOTICE

FAILURE TO FOLLOW THE MAINTENANCE SCHEDULE DESCRIBED IN THIS SECTION COULD ALTER OR VOID THE WARRANTY PROVIDED BY APPLIED ROBOTICS, INC.

The following table provides a schedule for preventive maintenance to be performed for the Epsilon Tool Changer.

Table 8-1. Preventive Maintenance Schedule

		Frequency of Maintenance				
		Every 2 Weeks	250,000 Cycles	500,000 Cycles	750,000 Cycles	1,000,000 Cycles
Robot Adaptor	Visual Checks (Section 7.1.2.1)	Lubrication (Section 7.1.1.1) & Visual Checks (Section 7.1.2.1)			Lubrication (Section 7.1.1.1) & Visual Checks (Section 7.1.2.1) & Replace Locating Pins if Worn or Damaged & Inspect Piston Spring Functionality and Replace if Necessary ¹	
Tool Adaptor	Visual Checks (Section 7.1.2.2)	Lubrication (Section 7.1.1.2) & Visual Checks (Section 7.1.2.2)			Lubrication (Section 7.1.1.2) & Visual Checks (Section 7.1.2.2) & Replace Locating Bushings if Worn or Damaged	

		Frequency of Maintenance				
		Every 2 Weeks	1,250,000 Cycles	1,500,000 Cycles	1,750,000 Cycles	2,000,000 Cycles ²
Robot Adaptor	Visual Checks (Section 7.1.2.1)	Lubrication (Section 7.1.1.1) & Visual Checks (Section 7.1.2.1)			Lubrication (Section 7.1.1.1) & Visual Checks (Section 7.1.2.1) & Inspect the Following Parts for Wear or Damage and Replace if Necessary: Locating Pins, Piston Head, Piston O-Ring, Cam Shaft, Cams. & Inspect Piston Spring Functionality and Replace if Necessary	
Tool Adaptor	Visual Checks (Section 7.1.2.2)	Lubrication (Section 7.1.1.2) & Visual Checks (Section 7.1.2.2)			Lubrication (Section 7.1.1.2) & Visual Checks (Section 7.1.2.2) & Replace Cam Pickup Dowels if Worn or Damaged & Replace Locating Bushings if Worn or Damaged	

¹ To test Piston Spring functionality, retract the cams (Figure 6.1-2) using air pressure, then completely vent off all air and ensure that the cams return to the extended position (Figure 6.1-1).

² Continue Lubrication and Visual Checks every 250,000 Cycles. Continue inspecting for wear or damaged components every 500,000 cycles.

8.1 PREVENTIVE MAINTENANCE

8.1.1 Lubrication

Proper lubrication of wear components is essential to maintaining the performance and prolonging the operational life of the E50 Tool Changer. Failure to apply proper lubrication could result in increased wear and shorten the life expectancy of the Tool Changer. The following lubricants are approved for use on the E50 Tool Change System.

Table 8.1.1-1. Approved Lubricants

Lubricant	ARI Part #	Manufacturer	Manufacturer's Part #
Lube-A-Cyl	51120	Parker	0766130000
White Lithium Grease	91504-P1037	Century Lubricants	ST-80
Staburags NBU 30 Grease	0903-P11N	Klüber	NBU 30
White EP Bearing Grease	96503-P1018	Dow Corning	White EP Bearing Grease

8.1.1.1 Robot Adaptor

1. Clean the latching cams, locating/alignment pins, and driver/washer to ensure all existing grease, dirt, and debris is removed.
2. Apply a liberal coating of white lithium grease to the contact surfaces on the three (3) latching cams, the cylindrical surfaces of the locating/alignment pins, and the contact surfaces between the latching cams and driver, as shown in Figure 8.1.1.1-1 and Figure 8.1.1.1-2 with the surfaces highlighted blue.




Figure 8.1.1.1-1. E50 Robot Adaptor Lubrication – Locating Pins & Cams




Figure 8.1.1.1-2. E50 Robot Adaptor Lubrication – Cams & Washer

8.1.1.2 Tool Adaptor

1. Clean the inner surface of the tool ring, the locating/alignment bushings, and the latching surfaces to ensure all existing grease, dirt, and debris is removed.
2. Apply a liberal coating of white lithium grease to the latching surfaces and to the inner surface of the locating/alignment bushings, as shown in Figure 8.1.1.2-1 with the surfaces highlighted blue.




Figure 8.1.1.2-1. ET63 Tool Adaptor Lubrication

8.1.2 Visual Checks

Periodic visual checks of the E50 Tool Changer provide early detection of breakage or wearing components.

8.1.2.1 Robot Adaptor

1. The latching cams and locating/alignment pins should be inspected for proper lubrication as defined in Section 8.1.1.1.
2. Inspect the latching cams and locating/alignment pins for rust, breakage, or wear³.
3. Inspect the Robot Adaptor mating surface for raised material⁴ or dings that could prevent proper mating to the Tool Adaptor.
4. Uncouple the Robot Adaptor from the Tool Adaptor and cycle the coupling mechanism several times to verify the latching cams are operating smoothly. The cycling of the coupling mechanism will also ensure that the operating cylinder remains properly lubricated.




Figure 8.1.2.1-1. E50 Robot Adaptor Visual Inspection

³ If excessive wear is found on the locating/alignment pins, latching cams, or Robot Adaptor mating surface, review the docking and undocking sequence of the robot program and adjust if necessary.

⁴ All raised material should be filed smooth.

8.1.2.2 Tool Adaptor

1. The locating/alignment bushings and the latching surfaces should be inspected for proper lubrication as defined in Section 8.1.1.2.
2. Inspect the latching surfaces and locating/alignment bushings for rust, breakage, or wear⁵.
3. Inspect the Tool Adaptor mating surface for raised material⁶ or dings that could prevent proper mating to the Robot Adaptor.




Figure 8.1.2.2-1. ET63 Tool Adaptor Visual Inspection

8.1.3 Checking Wear of the Cam Locking Mechanism

In the unlikely event that the Epsilon Tool Changer begins to demonstrate signs of wear in the cam locking mechanism, causing the connection between the Robot Adaptor and Tool Adaptor to lose repeatability and precision, the following can be used to check the wear of the locking mechanism.

1. Remove the Robot Adaptor from the Robot/Manipulator.
2. Remove the Tool Adaptor from the Tool.
3. Remove the face seals from the Robot Adaptor.
4. With the adaptors positioned on a workbench, inspect the mating surfaces of the Robot (Figure 8.1.3-1) and Tool (Figure 8.1.3-2) Adaptor for any raised material. If any raised material is found, file it smooth before proceeding.

⁵ If excessive wear is found on the locating/alignment bushings, latching surfaces, or Tool Adaptor mating surface, review the docking and undocking sequence of the robot program and adjust if necessary.

⁶ All raised material should be filed smooth.




Figure 8.1.3-1. Robot Adaptor – Raised Material Inspection




Figure 8.1.3-2. Tool Adaptor – Raised Material Inspection

5. Connect the couple and uncouple actuation port lines (Figure 5.3-1) so that the locking mechanism can be manually actuated.
6. With the cams retracted (Figure 6.1-2), position the Robot Adaptor and Tool Adaptor so that they can be coupled together.
7. Place a 0.05mm piece of shim stock at the locations shown in Figure 8.1.3-3, one location at a time.
8. Actuate the cams to couple the Robot Adaptor to the Tool Adaptor (Figure 6.1-1).
9. With a slight tug, check if the piece of shim stock is securely clamped between the Robot Adaptor and Tool Adaptor interface surfaces.
10. Uncouple the Robot Adaptor from the Tool Adaptor.
11. Repeat steps 6 through 9 for each location shown in Figure 8.1.3-3.




Figure 8.1.3-3. Shim Test of the Cam Locking Mechanism

If the piece of shim stock is able to be pulled free from the coupling interface while the cams are actuated (Figure 6.1-1), record the serial number of the Robot Adaptor and Tool Adaptor and contact APPLIED ROBOTICS Technical Support Department at (518) 384-1000 or techsupport@appliedrobotics.com.

9 SPARE PARTS

The spare parts listed below are recommended to be maintained in stock for the life of the Tool Changer. These quantities are based on a single unit. If higher quantities are purchased, please contact the Technical Support Department at (518) 384-1000 or techsupport@appliedrobotics.com to determine the quantity of spares recommended for the size of your installation.

Table 9-1. Robot Adaptor Spare Parts

ROBOT ADAPTOR		
Description	Part Number	Quantity
PIN, LOCATING XC5/CXC10	90507-B1028	2
SUBASSY, PNP M12 5PIN MOD. ER50/63 (Optional)	1507-D54A	1
O-RING, .112 ID X .103 BUNA	0202-P05N	8

Table 9-2. Tool Adaptor Spare Parts

TOOL ADAPTOR		
Description	Part Number	Quantity
LOCK RING, XC10 TOOLING	96503-B1054	1
BUSHING, (SS) XC5	90507-B1029	2

10 SPARE PARTS REPLACEMENT

The following procedures explain the correct method for removing and replacing the recommended spare parts listed in Section 9 of this manual.

10.1 ROBOT ADAPTOR

10.1.1 Locating/Alignment Pins

1. Remove the Robot Adaptor from the Robot/Manipulator.
2. Remove the M3 socket head cap screw (48030) using a 2.5mm allen wrench.
3. Remove round Locating Pin(s) (90507-B1028). Locating/Alignment Pins may need to be punched out.
4. Place new Locating Pin into the appropriate mounting hole (Figure 10.1.1-1).
5. Apply Loctite 242, or equivalent, to M3 socket head cap screw removed in step 2 (Clean threads before applying thread locker) and thread it into the Locating Pin from the top side of the Robot Adaptor Housing. Tighten until Locating Pins are no longer pulled into holes and do not rotate.
6. Lubricate Locating Pin per Section 8.1.1.1.




Figure 10.1.1-1. Locating/Alignment Pin Replacement

10.1.2 Couple/Uncouple Sensing Module (Optional Feature)

1. Remove the module (1507-D54A).
2. Loosen the captivated socket head cap screws holding the Sensing Module using a 2mm allen wrench.
3. Remove the Sensing Module and either discard or send to APPLIED ROBOTICS for repair.
4. Replace unit with another Sensing Module.
5. Ensure that the cavity in the Robot Adaptor Housing holding the Sensing Module is free of all foreign objects.
6. Ensure that the two (2) o-rings (97501-P1084) for the proximity sensors, supplied with the Sensing Module, are properly positioned.
7. Apply Loctite 242, or equivalent, to the threads of the captivated socket head cap screws before installing.
8. Install the new Sensing Module using the captivated socket head cap screws.
9. Prior to coupling the Tool Changer, cycle the actuating cylinder for the Robot Adaptor several times to ensure that the sensors are working properly and the correct inputs are being received by the robot controller.




Figure 10.1.2-1. Couple/Uncouple Sensing (Optional) Module Replacement

NOTICE

MAKING CONNECTIONS WHILE UNDER POWER COULD RESULT IN DAMAGE TO THE EQUIPMENT. TO AVOID DAMAGING EQUIPMENT, ENSURE THAT ALL CABLES ARE CONNECTED BEFORE SUPPLYING POWER TO THE EQUIPMENT.

10.2 TOOL ADAPTOR

10.2.1 Locking Ring

1. Remove the Tool Adaptor from the Tool.
2. Remove the M3 socket head set screws (48417) using a 1.5mm allen wrench.
3. Remove the Locking Ring (96503-B1054) from the Tool Adaptor. Note that an access hole is available if a punch is needed to remove the Locking Ring.
4. Place new Locking Ring into the Tool Adaptor.
5. Apply Loctite 222, or equivalent, to M3 socket head set screws removed in step 2 (clean threads before applying thread locker) and screw into the Tool Adaptor Housing.
6. Lubricate Latching Dowels per Section 8.1.1.2.




Figure 10.2.1-1. Locking Ring

10.2.2 Locating Bushing

1. Remove the Tool Adaptor from the Tool.
2. Press out the Locating Bushings (90507-B1029) from the bottom of the Tool Adaptor Housing.
3. Press in new Locating Bushings from the top of the Tool Adaptor Housing until it is just below the Tool Adaptor Housing surface. Ensure that the rounded edge of the Locating Bushing faces the top surface of the Tool Adaptor Housing.
4. Lubricate the Locating Bushing per Section 8.1.1.2.




Figure 10.2.2-1. Locating Bushing Replacement

11 INFORMATIONAL DRAWINGS

The drawings in this section can assist with installation, use and identification of replacement parts for the Epsilon Tool Changer. Please contact **APPLIED ROBOTICS Technical Support** if you have any questions.

DRAWING NUMBER	DESCRIPTION
1507-D40A	ER50-N/A-040-N-0-C0000
1507-D49A	ET63-040-N-C0000

